






RIGHT HAND SWING INSTALL
STEP 1 ATTACH BACKBOX TO WALL
STEP 2 ATTACH CABINET TO BACKBOX



STEP 1 R/HAND SWING
-ATTACH BACKBOX TO WALL (4) PLACES AS SHOWN
NOTE: PLASTIC RUNNERS ON BOTTOM
BRASS BUSHINGS ON RIGHT SIDE

WARNING: BACKBOX MUST BE SECURED TO WALL BEFORE INSTALLING CABINET

TRI VIEW CABINET REF
NOTE: NEVER INVERT CABINET



STEP 2 R/HAND SWING
-PLACE CABINET INTO BACK BOX AS SHOWN.
-TAKE 3/8 SCREWS THEN TIGHTEN WITH ALLEN WRENCH IN MATING RIVNUTS IN CABINET.
-THEN SECURE BOTH SCREWS WITH LOCK NUTS INSIDE THE CABINET.

HARDWARE BAG SHIPS WITH CABINET


- CONTENTS:**
- (1) ALLEN WRENCH
 - (2) CAP SCREWS
 - (2) NUTS
 - (2) SETS OF KEYS
 - (1) RS BAG OF SCREWS
 - (1) INSTALL SHEET

BACKBOX SHIPS WITH ADDITIONAL INSTALL SHEET

SEE PAGE 2 FOR LEFT HAND SWING ASSEMBLY


BACK BOX LEFT HAND SWING CHANGES BEFORE MOUNTING TO WALL:

- **INVERT BACKBOX AS SHIPPED** FOR R/HAND SWING
- MOVE PLASTIC STRIPS TO BOTTOM
- MOVE BRASS BUSHING PLATE TO BOTTOM LEFT
- MOVE BRASS BUSHING PLATE ON TOP LEFT



STEP 1 L/HAND SWING -ATTACH BACKBOX TO WALL (4) PLACES AS SHOWN


WARNING: BACKBOX MUST BE SECURED TO WALL BEFORE INSTALLING CABINET





STEP 2 L/HAND SWING -PLACE CABINET INTO BACK BOX AS SHOWN. -TAKE 3/8 SCREWS THEN TIGHTEN WITH ALLEN WRENCH IN MATING RIVNUTS IN CABINET. -THEN SECURE BOTH SCREWS WITH LOCK NUTS INSIDE THE CABINET.

CABINET LEFT HAND SWING CHANGE:

- MOVE "U" BRACKET TO LEFT



TRI VIEW CABINET REF.
NOTE: NEVER INVERT CABINET



HARDWARE BAG SHIPS WITH CABINET CONTENTS:

- (1) ALLEN WRENCH
- (2) CAP SCREWS
- (2) NUTS
- (2) SETS OF KEYS
- (1) RS BAG OF SCREWS
- (1) INSTALL SHEET

BACKBOX SHIPS WITH ADDITIONAL INSTALL SHEET